

## Frontier Flashing Kit for Sheds

1. Cut silicone cone for the relevant pipe size.
2. Slide flashing and silicone cone down over the pipe. Water can be used as a lubricant.
3. Apply silicone sealant on underside edge of metal flange.
4. Press flashing firmly onto contour of roof.
5. Fasten flashing to surface with the self-drilling screws, fitting progressively outwards to avoid gaps.
6. Finally attach self-drilling screw caps.